

**SUITABLE FOR WET LOCATIONS
TYPE IC - INHERENTLY PROTECTED
LEDS ARE NOT REPLACEABLE**



IMPORTANT SAFETY INSTRUCTIONS:

ENG

ANY MODIFICATION TO THIS FITTING IS FORBIDDEN WITHOUT PRIOR AUTHORIZATION

- Risk of fire/electric shock: turn off power before installation or maintenance.
- Risk of fire/electric shock: fixtures should always be installed, inspected and maintained in accordance with local and national electric codes by qualified electricians only.
- Risk of burning: make sure fixture is cool when performing maintenance.
- Risk of burning: keep fixtures away from materials that may burn.
- Perform electrical and mechanical maintenance on a regular basis at least once per year. Harsh environments might require more frequent controls.
- Do not operate the fixtures with a missing or damaged shield.
- Do not place the fixture in contact with corrosive substances such as fertilizers, weed killers or detergents.
- Fixture screens should be cleaned on regular basis to ensure lighting performance are maintained.
- All gaskets, O-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition.
- Avoid installing during rainy days.
- It is recommended to light up the fixture for at least 30min, without the glass screen, to remove any residual humidity trapped inside.
- Read carefully these instruction before installing the fixture and retain for future reference.

SAVE THESE INSTRUCTIONS

Note: specifications and dimensions subject to change without notice.


This data sheet and other technical documents continually updated can be accessed at www.arcluce-us.com.



TOOLS

- 3mm Allen wrench
- Small slotted screwdriver
- Philips screwdriver

SPECIFICATION



WEIGHT **4.85 lb**

RATED T_A **25°C**

WIRING **S**

Mains Voltage 120 - 277V

Typical power consumption **14W**

Dimming 0-10V

INSTALLATION

- 1 Drill hole in the ceiling of appropriate size, see figure 1.
- 2 Remove fixture trim (four 3mm hex screws) and glass, see figure 2.
- 3 Separate heatsink with LED board from body removing the two Philips screws and gently pulling on the two plastic straps, see figure 3.
4. Wire the fixture using appropriate cable rated for water protection according to diagram, see figure 4.
5. Position in drilled hole the fixture body and tighten the brackets (two Philips screws), see figure 5.
6. Clean the gasket and reassemble the trim. See figure 6.

1

Concrete

7"

11"

7"

Ensure the ceiling can firmly retain the fixture.

2

↑

3

Do not touch the lens.

4

Use only water rated cables (by others).

OD= \varnothing 1/4"-1/2"

- RED / DIM+
- BLACK / LINE
- GREEN / GROUND
- WHITE / NEUTRAL
- BROWN / DIM-

D+ L N D-

5

Before positioning the screen make sure the gaskets and sealing surfaces are clean.

6

↑

Data emissione: 2017.07.25

Stato di modifica: M0

Codice: 6552581.11